



Tool Model: AVANTI 5 DUAL-REAR ARM
Pressure/Torque Conversion Chart

PRESSURE IN: PSI	TORQUE IN:			PRESSURE IN: BAR
	ft-lbs	KGM	NM	
1500	802	111	1087	104
1600	857	119	1162	110
1800	967	134	1311	124
2000	1077	149	1460	138
2200	1185	164	1607	152
2400	293	179	1753	165
2600	1402	194	1900	179
2800	1510	209	2047	193
3000	1618	224	2193	207
3200	1728	129	2342	220
3400	1838	254	2492	234
3600	1948	269	2641	248
3800	2058	285	2790	262
4000	2168	300	2939	276
4200	2279	315	3090	290
4400	2390	331	3240	303
4600	2502	346	3391	317
4800	2613	361	3542	331
5000	2724	377	3693	345
5200	2835	392	3843	358
5400	2946	407	3993	372
5600	3056	423	4143	386
5800	3167	438	4293	400
6000	3278	453	4444	414
6200	3388	469	4593	427
6400	3499	484	4743	441
6600	3609	499	4893	455
6800	3720	514	5042	468
7000	3830	530	5192	482
7200	3939	545	5340	496
7400	4048	560	5488	510
7600	4158	575	5636	524
7800	4267	590	5784	538
8000	4376	605	5932	552
8200	4485	620	6080	565
8400	4594	635	6228	579
8600	4703	650	6375	593
8800	4812	665	6523	607
9000	4921	681	6671	620
9200	5029	695	6817	634
9400	5136	710	6963	648
9600	5244	725	7108	662
9800	5251	740	7254	676
10000	5459	755	7400	690

Hytorc West

<http://www.hytorcwest.com>